

SERIES 4300 VERTICAL IN-LINE PUMP | PORT SIZES: 16" × 16" | SERVICE WORK INSTRUCTIONS

File No: 43.815

Date: SEPTEMBER 29, 2016

Supersedes: 43.815

Date: JANUARY 27, 2009

LOWER BEARING REPLACEMENT PROCEDURE:

- 1 Stop the pump. Lock off the breaker. Isolate and drain the pump.
- 2 Remove lower bearing flush line ① from the bottom of casing.
- Remove the eight bolts 2 from the lower bearing cover 3 and remove the cover and gasket.
- 4 Check clearance between shaft and bearing. If 0.015" (0.38 mm) or greater the bearing should be replaced.
- 5 Remove the four bolts 4 from lower bearing 5 and relocate three of them into the tapped holes on lower bearing flange.
- 6 Tightening three bolts in sequence slowly and evenly, jacking out the lower bearing. Bearing-puller or longer bolts (see item 8) can be used to complete the removal of the bearing.
- 7 Ensure mating bore on casing, between casing and lower bearing, is clean.
- 8 Insert new lower bearing into the casing bore. Use two studs \%-16 \times 5" long with nuts (a) 180° apart to install lower bearing into the casing bore. Tightening stud nuts (a) slowly and evenly, lower bearing will slide into the casing bore (FIG. 3).
- 9 When lower bearing (5) is close to being fully installed, replace long studs (6) by bolts (4) and complete the installation.
- 10 Install new gasket 7 if necessary and place lower bearing cover 3.
- 11 Tighten all eight bolts ② evenly and equally and re-install flush line ①.

REPLACEMENT PART NUMBERS:

- 1 Lower bearing for 16×16×15 427494-000
- 2 Lower bearing for 16×16×19 427524-000
- **3** Gasket 426401-003





FIG. 1



TAPPED HOLES, THREE PLACES 180° APART FOR LOWER BEARING REPLACEMENT

FIG. 2




FIG. 3

TORONTO

23 BERTRAND AVENUE TORONTO, ONTARIO CANADA M1L 2P3 +1 416 755 2291

BUFFALO

93 EAST AVENUE NORTH TONAWANDA, NEW YORK U.S.A. 14120-6594 +1 716 693 8813

BIRMINGHAM

HEYWOOD WHARF, MUCKLOW HILL HALESOWEN, WEST MIDLANDS UNITED KINGDOM B62 8DJ +44 (0) 8444 145 145

MANCHESTER

WOLVERTON STREET
MANCHESTER
UNITED KINGDOM
M11 2ET
+44 (0) 8444 145 145

BANGALORE

#59, FIRST FLOOR, 3RD MAIN MARGOSA ROAD, MALLESWARAM BANGALORE, INDIA 560 003 +91 (0) 80 4906 3555

SHANGHAI

NO. 1619 HU HANG ROAD, XI DU TOWNSHIP FENG XIAN DISTRICT, SHANGHAI P.R.C. 201401 +86 21 3756 6696

SÃO PAULO

RUA JOSÉ SEMIÃO RODRIGUES AGOSTINHO, 1370 GALPÃO 6 EMBU DAS ARTES SAO PAULO, BRAZIL +55 11 4781 5500

ARMSTRONG FLUID TECHNOLOGY ESTABLISHED 1934

ARMSTRONGFLUIDTECHNOLOGY.COM

